

<b>PO Number</b>	KM1704-003
<b>Supplier</b>	Winnie Lam
<b>Supplier QA Notes</b>	<p>* Check that each master carton includes shipping marks on each master carton that includes: PO number, SKU value, abbreviated product name, carton configuration (units per case), case dimensions, net weight, gross weight, and country of manufacture (ie. Made in China) . Using metric measurements.</p> <p>* If the destination of the shipment is an Amazon FBA fulfilment centre, each master carton will have one FBA case label.</p> <p>* If the destination of the shipment is our 3PL warehouse (Warehouse Republic), each master carton will have one warehouse barcode label. Additionally, there will be one simplified visual sticker on each master carton, which shows the product shape, colour, and product size.</p> <p>* A product 'insert' will be included inside the packaging for each unit.</p> <p>* Signed reference samples are available at the factory locations and are signed as 'Winnie' or 'Keith'.</p> <p>* Any box that weighs more than 15kg (33 lbs) must contain "Team Lift"/"Heavy Package" safety label displayed on top and sides of each heavy-weight box (5 labels in total).</p>
<b>Freight Forwarder</b>	Flexport
<b>Shipment ID</b>	<a href="#">89005</a>

Product	Merchant SKU	QA Notes
SUMO Scoop (Blue) <a href="https://www.amazon.com/dp/B00YMIT5LQ">https://www.amazon.com/dp/B00YMIT5LQ</a>	FH-R59Y-OCMH	<p>* Make sure that the scoops have no chips, no dried glue residues, and no other kinds of damage.</p> <p>* Make sure the packaging has no damage.</p> <p>* Make sure the scoops are not dirty and have no scratches.</p> <p>* Only apply a '3PL WMS Barcode' case label if the shipment is to be sent to a 3PL warehouse. If the shipment is sent to Amazon FBA, then these labels are not required.</p> <p>* An additional 'Team Lift/Heavy Package' label is required if the case weighs more than 50lbs (22.7kg).</p>
SUMO Scoop (Green) <a href="https://www.amazon.com/dp/B00YMIT300">https://www.amazon.com/dp/B00YMIT300</a>	LE-J42W-SUNZ	<p>* Make sure that the scoops have no chips, no dried glue residues, and no other kinds of damage.</p> <p>* Make sure the packaging has no damage.</p> <p>* Make sure the scoops are not dirty and have no scratches.</p> <p>* Only apply a '3PL WMS Barcode' case label if the shipment is to be sent to a 3PL warehouse. If the shipment is sent to Amazon FBA, then these labels are not required.</p> <p>* An additional 'Team Lift/Heavy Package' label is required if the case weighs more than 50lbs (22.7kg).</p>
SUMO Scoop (Purple) <a href="https://www.amazon.com/dp/B00PTSTST2">https://www.amazon.com/dp/B00PTSTST2</a>	BX-P16J-ESZX-B	<p>* Make sure that the scoops have no chips, no dried glue residues, and no other kinds of damage.</p> <p>* Make sure the packaging has no damage.</p> <p>* Make sure the scoops are not dirty and have no scratches.</p> <p>* Only apply a '3PL WMS Barcode' case label if the shipment is to be sent to a 3PL warehouse. If the shipment is sent to Amazon FBA, then these labels are not required.</p> <p>* An additional 'Team Lift/Heavy Package' label is required if the case weighs more than 50lbs (22.7kg).</p>